

# **AT110 model Maintenance Manual**

## **Compilation Illustration**

This maintenance manual introduces the maintenance adjustment procedure, disassembly and assembly essentials, inspection and maintenance points, troubleshooting methods and maintenance technical data of AT110 model (ATV) (four-wheel all-terrain vehicle) in detail, with detailed graphic data attached to guide the operation.

Please carefully read this manual and conduct inspection and repair in accordance with the standard operating practices, which can effectively extend the service life of each part, improve the performance of the engine and the reliability of the whole vehicle.

## Content

Chapter 1: Maintenance Information

Chapter 2: Vehicle Body & Plastic Parts

Chapter 3: Check and adjust regularly

Chapter 4: External Components of the Engine

Chapter5: Engine

**Note: Please understand that the contents in this maintenance manual which subject to change due to vehicle improvement, upgrading will not notify again. The actual condition of the vehicle shall prevail in the maintenance.**

ZHE JIANG KAYO MOTOR CO., LTD

## Unit Conversion Covered in the Manual

Item	Unit Conversion
Pressure	1kgf/cm <sup>2</sup> =98.0665kPa; 1kPa=1000Pa
	1PSI=0.0689kgf/cm <sup>2</sup>
	1mmHg=133.322Pa=0.133322kPa
Torque	1kgf·m=9.80665N·m
Volume	1mL=1cm <sup>3</sup> =1cc
	1L=1000cm <sup>3</sup>
moment of force	1kgf=9.80665N
Length	1in=25.4mm

## Danger/warning/caution

Please read the following explanation carefully. It emphasizes the special meaning of the words "danger", "warning" and "attention". Special attention should be paid to the prominent meaning in the whole vehicle and engine maintenance.

**Danger:** Means to be alert to high danger

**Warning:** Indicates caution against moderate danger

**Caution:** Indicates concern for minor hazards

However, it is important to note that the "hazards" and "warnings" contained in this maintenance manual cannot cover all potential hazards in the process of engine use and maintenance. Therefore, in addition to the "danger" and "warning" regulations, maintenance personnel must also have basic mechanical safety knowledge. If the operator is not sure to complete the entire maintenance operation process, please consult more experienced senior technicians.

## Maintenance information

- 1.1 Notes for Operation
- 1.2 Vehicle identification code
- 1.3 Main parameter table
- 1.4 Maintenance parameters table
- 1.5 Tighten torque
- 1.6 Lubrication and sealing
- 1.7 Cable, hose and cable wiring diagram

### 1.1 Notes for Operation

#### Safety precautions

1. Work clothes (jumpsuits), hats, safety boots must be worn. When necessary, safety protective

## ZHE JIANG KAYO MOTOR CO., LTD

---

equipment such as dustproof glasses, dustproof masks and gloves should be put on to protect yourself from injury.

2. Because the exhaust gas contains harmful components, it is prohibited to operate the engine in closed places and places with poor ventilation for a long time.
3. When the engine is shut down, the temperature of the engine and muffler is very high, so that it cannot be touched before cooling to avoid burns.
4. The battery solution (dilute sulfuric acid) is a corrosive agent, which may cause burns and blindness when it touches the skin and splashes into the eyes. In case of accidental contact with battery solution on clothes and skin, flush with plenty of water immediately; in case of accidental contact with battery solution on eyes, please flush with plenty of water immediately and go to the hospital in time for treatment. Batteries and battery solutions should be kept strictly and must be placed in a safe place out of reach of children. Battery charging is able to produce flammable and explosive hydrogen, once there is a fire or electric spark near, there is an explosion risk. Therefore, please charge in a well-ventilated place.
5. As gasoline is flammable and explosive, fireworks are strictly prohibited in the work site. Watch not only for open flames, but also for electric sparks. Vaporized gasoline is at risk of explosion. Please choose a well-ventilated site for operation.
6. Do not let the rear-wheel, clutch or other rotating parts and movable parts clamp hands and clothes at any time during maintenance.
7. When two or more people work together, they must continuously greet each other to ensure safety.

### **Disassembly and assembly Note**

1. Components, lubricants and lipids must be made from genuine parts of Kayo brand or recommended parts designated by Kayo.
2. After the vehicle is disassembled, the parts of each system shall be sorted out and kept separately to ensure that the parts can be put back to their original position.
3. Please clean the dirt and dust of the vehicle before maintenance.
4. The gasket, o-ring, piston pin retainer, opening pin and other parts must be replaced after disassembly. Replace the lock nut according to damage situation after removal.
5. When the elastic baffle, spring, and steel wire baffle are disassembled, if the opening is too large, it will cause irreversible plastic deformation, resulting in the failure of parts, which will be easy to fall off after re-assembly. Please do not use already loose, lose the flexibility of this kind of article to replace new one in time.
6. After the parts are disassembled and checked, clean them before measurement and blow off the cleaning agent with compressed air. Oil or grease should be applied on the movement surface before assembly.
7. When disassembly, necessary parts shall be inspected, relevant data measured and even pictures taken. So that the assembly is able to revert to the previous state of disassembly.
8. Bolts, nuts and screw fasteners must first be threaded with 2~3 turns of thread, and then tightened on the diagonal in accordance with the principle of from big to

small and from inside out according to the prescribed tightening torque.

9. Rubber parts should be inspected for aging during disassembly and replaced in advance if necessary. Rubber parts are not resistant to gasoline and kerosene corrosion, try not to allow volatile oil, grease kind of touch.

10. The recommended grease should be applied or injected into the designated parts as required by the maintenance manual.

11. Correct special tools should be used for disassembly and assembly.

12. When deep groove ball bearing is disassembled, it adopts the disassembly method of internal ring force, so the removed bearing shall not be used again, and shall be replaced in time.

Deep groove ball bearings can be used finger rotation, if abnormal sound, stuck, bearing should be replaced.

Bearing axial. If the radial clearance is too large, it shall be replaced.

Bearing and the original on the body or diameter of the original pressure to fit, after the disassembly of the fit is not tight should be replaced.

13. The bearing should be coated with machine oil or grease before assembling. One-sided bearings need to pay attention to the direction of assembly. Open type, double-sided dust-proof cover bearing in the assembly of the manufacturer's logo, the size of the face outward installation.

14. When installing elastic baffle, one side with chamfer should be turned out. Do not use loose retainers. Rotate the elastic baffle after assembly and make sure the baffle is installed in the groove.

15. After assembly, please check whether the fasteners are tightened and working properly.

16. Brake fluid, gasoline and oil will corrode the coating surface, plastic parts, rubber parts, etc. Special care should be taken to prevent the above liquid from touching during disassembly and assembly.

17. The oil seal shall be installed outward with one side marked by the manufacturer. Check to make sure the spring coil inside the oil seal is intact.

Note lip crimping, broken, crack can not be used.

Smear grease on the oil seal surface to prevent burrs from scratching the oil seal lip.

18. When installing hose parts, the hose must be checked to the root of the joint. Tubing clips must be installed to the hollow of the pipe. Loose hose must be replaced during installation.

19. Pay attention to dust prevention during vehicle maintenance, and do not introduce dust and dirt into the engine, fuel tank and brake oil pressure system.

20. The gasket material attached to the joint surface of each box body of the engine can only be assembled after cleaning. To remove the contact mark on the surface, it must be polished evenly with oil stone.

21. The lasso should not be excessively twisted or bent. Deformation and damage to the cable will create a lag.

22. When assembling cap parts, the cap with groove must be installed into the groove.

### Engine Running-in

The engine has many relative moving parts, such as piston, piston ring, cylinder body, crankshaft, crank, connecting rod, intermeshing transmission gear and so on. Therefore, in the early use of these parts, the specification of running-in is necessary. The run-in can make the relative moving parts adapt to each other, correct the working clearance, and form a good smooth friction surface that can withstand large loads. Only when the engine is well-run can it have excellent performance, more stable reliability and extend the service life of the engine.

The recommended running time of the engine is 20 hours, and the specifications are as follows:

**0~10 hours:** avoid continuous operation in the state of 1/2 throttle opening, and change speed at the same time, it is not recommended to operate in a fixed throttle position for a long time. After working for 1 hour, stop the engine to cool down for 5 to 10 minutes to avoid rapid acceleration.

**10~20 hours:** avoid long operation when the throttle is over 3/4 open. Use the accelerator freely, but not full throttle.

#### Note:

As per the daily maintenance provisions during wear and repair, troubleshooting in time;


After the end of the grinding, the engine for 20 hours of grinding before maintenance can enter the normal driving stage

### 1.2 VIN

<b>Vehicle Model</b>	<b>HY110AT (AT110)</b>
<b>VIN</b>	
<b>ENGINE NO.</b>	

Inscription position See attached figure:

- 1) VIN on Chasis
- 2) Vehicle name plate
- 3) Engine No.



### 1.4 Main Parameters

No.	Item	
1	TRADE MARK	KAYO
2	MODEL	HY110AT
3	NAME	ATV 110cc Sport ATV
4	COMPANY	Zhejiang Kayo Motor Co., Ltd

### Main dimension parameters

1	Dimension(L*W*H) (mm)	1380*880*930
2	Height of Handle bar (mm)	930
3	Width of Handle bar (mm)	730
4	Height of Vehicle Tail (mm)	700
5	Seat Height (mm)	635
6	Ground Clearance(mm)	90
7	Wheel Base (mm)	900
8	Front wheel base	700

## ZHE JIANG KAYO MOTOR CO., LTD

9	Rear wheel base	640
10	Turning radius	1650
11	Steering angle(Degree)	38° ± 2°
12	Dry Weight(kg)	97.4 ± 2
13	Curb Weight(Battery + Fuel) (Kg)	102
14	Max. Speed Km/h	(Speed limitation) 40


### Engine parameters

No	Item		
1	Starting method		Electric start
2	Engine type		Horizontal Single cylinder, four stroke, air cooling
3	Air distribution		SOHC/Chain drive
4	Cylinder diameter × stroke (mm)		52.4*49.5
5	Compression ratio		9.0 :1
6	Lubrication method		Pressure + splash lubrication
7	Oil pump type		Rotor type
8	Lubricating oil filter type		Full flow filter rotary, Paper filter core
9	No. of Engine oil		SAE15W-40
10	Cooling		Air Cooling
11	Coolant		/
12	Air filter		Sponge filter cartridge
13	Carburetor		Flat suction plunger type (JINGKE PZ22/EPA)
14	Fuel Tank Capacity		2L
15	Clutch		Dry automatic clutch
16	Variable speed mode		1+1 Foot shifting, with shift protection.
17	Shift Gear		One forward gear, one reverse gear
18	Shift mode / sequence		R~N~D
19	Deceleration ratio		Forward Gear D      Reverse Gear R
		Primary Deceleration ratio	Clutch hub gear / primary transmission tooth
		Single stage deceleration ratio	Forward gear ratio      Forward gear ratio
		Total speed ratio	
<b>Chasis</b>			
20	Driving sprocket ratio		37/13
21	Output form		Chain drive, rear wheel drive
22	Brake		Front and rear disc brake

## ZHE JIANG KAYO MOTOR CO., LTD

23	Suspension	Double rocker independent type
24	Frame	Welded steel tube sheet

### Lubricating device

Item	Standard	limited	
Engine oil capacity	Change oil	800mL (No oil filter replaced)	—
	Change oil	800mL (oil filter replaced)	
	Full capacity	800mL	—
Recommended engine oil(See Original File)		Specilly used for 4-stroke motorcycle, if want to use other oil replace SAE-15W-40 Should used within following mentioned range	
 <p>The chart shows viscosity grades on the y-axis and temperature in °C and °F on the x-axis. Arrows indicate the recommended oil grades for different temperature ranges: 5W-30 for -30°C to 0°C, 10W-30 for -20°C to 10°C, 10W-40 for -10°C to 20°C, 10W-50 for 0°C to 30°C, 15W-40 for 10°C to 40°C, 15W-50 for 20°C to 40°C, and 20W-50 for 30°C to 40°C.</p>		<ul style="list-style-type: none"> <li>• API Classify: SG or higher engine oil.</li> <li>• SAE Specification: Choose start from left side table according to outside temperature.</li> </ul>	
Oil pump rotor	Internal and external rotor	0.07 mm~0.15mm	0.2mm
	Clearance between outer rotor	0.03 mm~0.10mm	0.12mm
	Oil pump rotor end clearance	0.023 mm ~0.055 mm	0.12 mm
	Oil pressure	1500r/min, 90°C时 200 kPa ~400kPa, Generally 240 kPa 6000r/min, 90°C 600 kPa ~700kPa, Generally 600 kPa	

**Intake system (see engine part)**

**Cooling device (no)**

**Wheel ( front and rear are the same )**

Item		Standard	limited
Rim pulsation	Vertical	1.0mm	2.0mm
	Horizontal	1.0mm	1.8mm
Tyre	Groove depth	~	3.0mm
	Air Pressure	4.0 PSI	~

### Brake System

Item		Standard	limited
Front Brake (1 drag 2)	Brake disc thickness	3.5mm	3mm
	Brake handle stroke	5~10mm	~
	Brake disc strength	400N*m	~
Rear Brake	Brake disc thickness	3.5mm	~
	Brake handle stroke	10~20mm	~

## ZHE JIANG KAYO MOTOR CO., LTD

	Brake disc strength	500 N*m	~
--	---------------------	---------	---

### Ignition device

Item		Standard
Ignition method		CDI Ignition
Sparking plug	Type	Resistive spark plug
	Standard	ATR7C/ ( torch )
	Spark plug gap	0.6~0.7mm
	Spark characteristics	>8mm,1 atmospheres
<b>Ignition advance angle</b>		
High voltage package resistance	Primary Resistance	0.43~0.57 Ω
	Second Resistance	10.1~11K Ω
Peak voltage	Ignition coil Primary	>150V
	Pulse generator	2V

### Light/Instrument/Switch

Item		Standard
Relay Chip Fuse		15A
Light	Front Left & Right Light	12V*3W*2
	Rear light / brake light	LED
	Shift Gear Indication Light	LED

Valve + Cylinder head (See Engine Section)

Cylinder + Piston + Piston Ring + Crank Link(See Engine Section)

### 1.5 Fastener tightening torque

**Note: When you install thread, you must manually bring 2~3 thread.**

Tightening torque at the designated part

The entire vehicle part

No.	Item	Installation Position	Bolt specification	Grade	TorqueN*m
1	Engine	Rear power bolt	M8	10.9 Grade	37~50
2		Upper power	M8	10.9 Grade	37~50

## ZHE JIANG KAYO MOTOR CO., LTD

		bolt			
3		Lower power bolt	M8	8.8 Grade	18~25
4	Suspension	Front and rear Suspension bolts	M10*1.25	8.8 Grade	35~45
5		Upper rocker shaft	M10*1.25	8.8 Grade	35~45
6		Lower rocker bolt	M10*1.25	10.9 Grade	58~71
7		Fork shaft	M12*1.25	8.8 Grade	50~60
8	Brake	Rear disc brake mounting	M8	8.8 Grade	18~25 ( Blue thread adhesive )
9		Front Disc brake mounting	M6	10.9 Grade	15~20
10		Disc brake pump Mounting	M8	10.9Grade	29~35
11		Front Brake Tee Installation	M8	8.8	18~25
12	Rear Axle	Rear Axle Mounting	M12*1.25	8.8	55~65
13		Big Nut	M27*1.5		80~90
14		Chain bolt	M6	8.8	8~12
15	Steering	Clip locking bolt(Inside hexagonal corners)	M8	10.9	18~25
16		Steering column locking	M8	8.8	18~25
17		Lower Pressure block mounting bolt	M10*1.5	10.9	50~60
18	Electrical devices	Battery Box Installation	M8	8.8	15~20
19		Muffler fastening	M8	8.8	15~20
20		Pressurizer high pressure	M6	8.8	7~11

## ZHE JIANG KAYO MOTOR CO., LTD

		package			
21	Fuel tank, Vehicle	Fuel Tank Installation	M6	8.8	7~11
22	Body, Plastic parts	Fuel Tank Switch	M6	8.8	7~11
23		Pedal Installation	M8	8.8	18~25
24		Steel Pedal	M6	8.8	8~12
25		Plastic Flat head	TM6		7~11
26		Self tapping pins for connection headlight with Plastic Parts.	ST4.2		3~5

**Tightening torque at the specified location - Engine section ( See Engine section )**

**Engine repair tool (See Engine section)**

**Engine-specific tools (See Engine section)**

### 1.6 Lubricating grease, sealant

No.	Smear Position	Function	Grease
1	Upper and lower rocker arm dust cover	Lubrication	XHP222
2	Upper and lower rocker ball head seat		
3	Steering column base		
4	Left and right steering knuckle joint with wheel hub		
5	Rear fork mounting shaft		
6	Rear flat fork inner liner		
7	Rear axle lining pipe		
8	Rear axle bearing oil seal		
9	Steering column clamp block		

**Note: The handle bar should to be glued first when install the grip**

**Engine running material and installation accessories (see engine part). Engine operating materials include lubricant (Engine oil), grease (yellow oil), etc.**

**Installation accessories include sealant, thread glue and so on.**

### 1.7 Cable Connection Layout



Main Cable


Front brake tubing

Throttle Cable

Rear brake tubing


Choke cable






- Brake cable connector
- Emergency flameout switch connector
- Neutral display connector
- Reverse display connector
- Switch lock connector
- Functional switch connector

Headlight connector



- Power anode
- Power cathode
- Magneto connector


- Rectifier regulator connector
- Gear display connector



Rectifier  
Regulator



Rear  
lamp



Ignition  
Coil



CDI

## 2 Vehicle Covers

2.1 Maintenance information

2.2 Mounting torque

2.3 Disassembly and assembly of seat cushion, front and rear protectives, front and rear mud plate, head cover, rear body, left and right protective plate, front body, left and right plastic pedals and left and right pedals

### 2.1 Maintenance information

Work notes:

1. When replacing the overlays with the warning signs affixed and riveted on the vehicles, the corresponding marks should be correctly and completely completed according to the original ones.
2. This chapter describes the disassembly sequence of vehicle body panels, and refers to this chapter when it is necessary to disassemble the related panels when repairing the internal parts of the vehicle.
3. This chapter only describes the disassembly and assembly. If the problem of cable, tubing and cable alignment is involved in the process of disassembly and assembly, please refer to the cable layout chart.

### 2.2 Mounting torque

M8 bolt: 18~25N\*m

TM6 Large headed bolt : 7~11 N\*m

M6\*bolt: 8~12 N\*m

**2.3 Dismantling and assembling of head cover, handle bar, seat cushion, whole vehicle plastic parts (front and rear fender, rear body, left and right footrest guard, front body), front guard assembly, left and right plastic parts of pedals, left and right pedals.**

#### 2.3.1 Head cover

##### Disassemble

1. Remove the fixing bolts 1 and 2 (2 in symmetrical position).
2. Push the head cover in the direction shown in the figure. Remove the head cover after the buckle is loosened.  
(Note: the buckle on the head cover is easy to break and operate carefully.)

Follow the reverse sequence and reverse direction of the disassembly. After installation, pay attention to checking whether the cushion is installed in place and reliable.

##### Assemble




### 2.3.2 Handle Bar

#### Disassemble

- 1, when dismantling the direction, first disconnect the vehicle power supply.
2. Use scissors to cut the plastic tie, and pull out the main plug of the multi-functional switch, the plug of the flameout switch and the plug of the brake wire in turn.
3. Release the handle bolt of the disc brake with the tool and remove the brake handle.

- 4, the front brake dismantling the rear brake.
- 5, Pull out the air door line according to the graphic direction, then remove the choke cable.
- 6, Screw the accelerator cap bolts with tools and remove the throttle cable.
- 7, Remove the pressing bolts, remove the upper block and remove the handle bar.



## Assemble

Follow the reverse sequence of dismantling, and check to see if the installation is in place.

(Note: 1) After the installation of the handle bar, the flameout switch connector, multi-functional switch connector and brake connector must be checked to prevent misconnection and loosening.

2, Check the choke cable, throttle cable is installed in place.

3, The front brake and rear brake is suitable for installation angle, and the handle bar is referenced to the vehicle wiring diagram.

### 2.3.3 CUSHION ASSEMBLE

#### DISASSEMBLE

1. Press the tail of the cushion and pull the seat hook at the same time.
2. Lift up the back of the cushion and pull the cushion back.



#### ASSEMBLE

Cushion hook

Follow the reverse sequence and reverse direction of the disassembly. After installation, pay attention to checking whether the cushion is installed in place and stable. (Note: The front hook of the seat cushion must be installed in the limit of the frame, and the limiting column of the seat cushion must be installed in the limit of the frame installation).

### 2.3.4 Front guard assembly

#### Disassembly

1. Remove the installation bolts of the front guard assembly in turn.
2. Remove the front guard assembly.



#### Assembly

WWW Mounting bolt

## ZHE JIANG KAYO MOTOR CO., LTD

Installation is done in reverse order.

(Note: If bolts and nuts are damaged, please replace new parts of the same specification in time.)

### 2.3.5 Vehicle plastic parts

#### Disassemble

Disconnect the electric lock plug, the neutral indicator lamp plug, the reverse indicator lamp plug, the left and right headlight plug.

Remove the fixed bolts 1/2, 3/4, 5/6, 7/8, 9/10 in turn. Note (2/4/6/8/10 on the other side of the vehicle)

Unscrew the oil tank cover and remove the whole vehicle plastic parts. (Note: During the maintenance process, the handle bar must be removed first when dismantling the vehicle plastic parts.)




Oil tank  
Cap

1 2

3

4 5



#### Assemble

Installation is done in reverse order.

(Note: If bolts and nuts are damaged, please replace new parts of the same specification in time. After installation, check the headlamp connector, the electric lock connector, the reverse indicator connector, the neutral indicator connector and so on to prevent loosening and misconnection.)

### 2.3.6 Front & Rear Fender

#### Dismantling of Left & right front fender

1. Remove the mounting bolts of the left fender in turn.
2. Remove the left front fenders.



#### Assemble

Installation is done in reverse order.

(Note: If bolts, nuts and rubber pads are damaged, please replace new parts of the same specification in time.)

Assemble & disassemble of the front right fender is same with front left fender.

#### Dismantling of left & right rear fender

1. Remove the mounting bolts of the left fender in turn.
2. Remove the left rear fenders.



**Install** Installation is done in reverse order.

## ZHE JIANG KAYO MOTOR CO., LTD

(Note: If bolts, nuts and rubber pads are damaged, please replace new parts of the same specification in time.)


Dismantling & Installation of the right rear fender are same with the left rear fender.

### 2.3.7 Rear Vehicle Body

#### Disassemble

(Remove rear body, left & right rear fenders)

1. Remove the rear body mounting bolt 1/2,3/4,5/6,7/8, (the mounting bolts are symmetrical on the vehicle body).
2. Remove the vehicle body.



#### Assemble

Installation is done in reverse order.

(Note: If bolts, nuts and rubber pads are damaged, please replace new parts of the same specification in time.)

### 2.3.8 Left & Right Guard Plate

#### Disassemble of the left guard plate

1. Remove the mounting bolts 1, 2, 3 and 4 of the left guard plate.  
Push the left guard plate according to the direction showed on the picture, loosen the buckle on the plastic part, and remove the left guard plate.



## Assemble

Installation is done in reverse order.

(Note: If bolts, nuts and rubber pads are damaged, please replace new parts of the same specification in time.)

Dismantling of the right guard plate are same with the left guard plate.

## 2.3.9 Front Vehicle Body

### Disassemble

(Note: Dismantling the handle bar when removing the vehicle body)

1. Remove the front body mounting bolts 1/2, 3/4 and unscrew the oil tank cap.
2. Release the electric lock plug, front and left headlight connector and take out the front vehicle body.



1/2      fuel tank cap      3/4



## Assemble

According to the reverse order of disassembly.


(Note: 1 If the bolts, nuts and rubber flat washer are damaged, please replace the new parts of the same specification in time.

2. Inspect headlamp connector, electric lock connector, reverse indicator connector and neutral indicator connector after installation to prevent loosening and misconnection.

### 2.3.10 Left & right footrest plastic parts

Disassembly of left plastic parts

1. Remove the plastic mounting bolts 1, 2 and 3.
2. Remove the left plastic parts



### **Assemble**

According to the reverse order of disassembly.


(Note: If bolts, nuts and rubber flat washer are damaged, please replace new parts of the same specification in time.)

The right plastic part is same with the left plastic part when dismantled .

### **2.3.11 Right & Left pedal**

#### **Disassemble of left pedal**

1. Remove the mounting bolts 1, 2, 3, 4 and 5 of the pedal.  
Go down the left foot pedal.



### **Assemble**

According to the reverse order of disassembly.

(Note: when the bolts are damaged, please replace the new parts of the same specification in time.

### 3. Regular inspection and adjustment

- |                                       |                               |
|---------------------------------------|-------------------------------|
| 3.1 Maintenance information           | 3.6 Suspension system         |
| 3.2 Set maintenance period            | 3.7 Gear shift & fuel devices |
| 3.3 Inspection and maintenance method | 3.8 Throttle checking         |
| 3.4 Steering column and brake system  | 3.9 Vehicle Light device      |
| 3.5 Wheel                             | 3.10 Shock absorber selection |

### 3.1 Maintenance Information

#### Operation Notes

- As the exhaust gas contains toxic components such as carbon monoxide (CO), please do not run the engine for a long time in closed or poorly ventilated places.
- When the engine has just stopped, the temperature of the muffler and the engine is still very high, and when it touches the skin, it will cause burns. If the engine must be repaired when it has just stopped, long-sleeved overalls and gloves must be worn for operation.
- Gasoline is very easy to cause fire, and fireworks are strictly prohibited in the workplace. We should not only pay attention to open fires, but also pay special attention to electrical sparks. In addition, due to the risk of explosion of the vaporized gasoline, the operation should be carried out in a well ventilated area.
- Be careful not to allow drivers and other rotary parts to clip their hands and clothes.

#### Be careful

**Vehicles must be placed in a flat and stable place.**

#### 3.2 Set maintenance period

Engine maintenance is a regular periodic work. It is very important to maintain the engine at a certain time interval. Normative maintenance can ensure excellent engine performance, reliable

## ZHE JIANG KAYO MOTOR CO., LTD

operation and economic durability. Here is the maintenance periodic table of A125 engine.

**Note:** The following table is designed according to the normal working condition. Under bad conditions, the maintenance cycle of the engine should be shortened accordingly.

A: Adjustment C: Clean I: Inspection L: Lubrication R : Replace	10hours or 300km				
	20hours or 750km				
	Each 50 hours or 1500km				
	Each 100 hours or 3000km or 1 year				
	200 hours or 6000km or 2 year				
Remarks					
Engine					
Lubricating oil filter		R		R	
Valve adjustment		I, A		I, A	
Engine tightness	I			I	
Engine suspension	I			I	
Air cleaner		C	R		
Spark plug		I		I	R
Fuel system					
Carburetor	I			I, L	
Driving wheel and driven wheel				I, C	
Clutch				I	

Inspection and maintenance items			Period of maintenance			Judging Standard
Maintenance Parts	Inspection Item		Daily	Half year	Year	
Steering Device	Handle Bar	Operation Flexibility	○			
	Steering System	Damage	○			
		Installation conditions	○			
		Shaking of Ball pin	○			
Brake Device	Brake handlebar	Brake stroke	○	○		
		Brake effect	○	○		
	Connecting rod and tubing	Loosening and damage	○		○	
	Hydraulic brake and brake disc	Brake Fluid Volume	○	○		Brake fluid should be at the lower limit.
Wear and damage of brake discs		○	○		Working disc thickness of brake disc at present When the disc is less than 3mm, it should be replaced in time.	

## ZHE JIANG KAYO MOTOR CO., LTD

	Brake disc	Wear and damage of brake pads	○	○		The minimum brake pad (friction plate) thickness $\geq$ 1.5mm; when less than 1.5mm, please replace it.	
Running Device	Vehicle Wheels	Tire Pressure	○	○		Front Tyre 45kPa ( 0.45kgf/ cm <sup>2</sup> ) (4.0PSI) Rear Tyre: 45kPa( 0.45kgf/cm <sup>2</sup> ) (4.0PSI)	
		Tyre cracking and damage	○	○	○		
		Tire groove depth and abnormal wear	○		○		If there is no appearance on the tire surface
		Loosening of wheel nuts and wheel shafts	○	○			
		Sway of front wheelbearings	○		○		
		Sway of rear wheel bearings	○		○		
Shock Device	suspension arm	Rocking of connecting part and damage of rocker arm	○		○		
	shock absorber	Oil-leaking & damage	○		○		
		Function			○		
Transmission Device	chain	Transmission, lubrication and tightness	○		○	Chain swinging up and down >20mm	
	Flywheel,Rear sprocket	Transmission, lubrication and tightness of fastening bolts	○		○	If the sprocket and chain are seriously worn, please replace the new parts in time.	
Electrical Device	Ignition device	Spark plug condition		○			
		Ignition period		○			
	Battery	Terminal connection status			○		
	Electric circuit	Loosening and damage at joints			○		
Fuel System		Fuel leaking		○			
		Throttle Condition			○	Throttle turn handle with clearance 3~5mm	
Light & Indicators		Function	○	○			
Exhaust Pipe & Muffler		loose or damage during Installation			○		
		Perfomance of the Muffler			○		
Vehicle Frame		loose or damage			○		
Others		Grease status of various parts of frame			○		
Abnormal part that can be identified in operation		Confirm whether the relevant part is abnormal.	○				

### 3.4 Steering stem, brake system

Stop the vehicle in a horizontal position and shake it as the direction shown in the picture to check if there is any shaking.



If you feel the shaking, check if the steering stem is shaking or other components are shaking and then make the corresponding maintenance. If the steering stem is shaking, increase the locking force of the lock nut of steering stem or disassemble it for repair.

Stop the car in a horizontal position and slowly turn the steering stem to the left and then right to confirm whether the rotation is flexible.



If there is any obstruction in some places, check the main cable, other cables, brake hose, etc.. If there isn't any problem, check if the powder metallurgy spacer which is at the end of the steering stem is stuck.

Note: It must be confirmed that the steering stem is flexible, otherwise the handle will cause an accident due to the inability to control the direction.

The clearance of the front and rear brake handles: Test the front and rear brake handles to check the braking effect. Clearance range of brake handle is 5-10mm.

### Brake pump combination

Check the amount of brake fluid. When the volume of brake fluid reduced to the lower limit position(LOWER), the vehicle cannot be used. Check the brake pump, brake pipe and joints for leaking. If there is no abnormality, open the upper cover of the brake handle to fill the DOT4 brake fluid above the lower limit position.



Note:

Do not mix dust and water when fill the brake fluid;

To prevent chemical changes, use the brake fluid which is specified number;

Brake fluid will damage the surface of plastic and rubber parts. Please do not splash it on such parts.

Wear of brake discs and brake friction plates(hoof blocks)

It is normal for the brake friction plates (hoof blocks) and brake discs to wear during the use of vehicle.

Inspection and replacement of Brake disc

Check the surface of sliding friction of the brake disc for wear, smashing, bumping, scratching or straining. And replace it in time.

When the thickness of the brake disc is less than 3mm, please replace it in time.

Inspection and replacement of brake friction plates (hoof blocks)

Check the maximum thickness of the brake friction plates (hoof block). If the thickness is less than 1.5mm, please replace it in time.

Check the brake friction plate (hoof block) for damage or cracks. And replace it in time.

Note:

Friction plate (hoof blocks) must be replaced in set.

### 3.5 Wheel

Lift the front wheel with the tool in the horizontal position, make sure that the body of vehicle has no force on the wheel, shake the front wheel from side to side, and check whether the connection of the front wheel is firm. Check if the front wheels shakes, if there is any shakes, please

Check the tightening bolts on the rocker arm, axle, and rim. If there is


still shaking, check the rocker shaft bushing, the ball cap and replace them.



#### Front bundle of the wheel

Stop the vehicle in a horizontal position and measure the size of front bundle of the wheel.

The front of the wheel relative to the direction of driving of the vehicle is A, the rear of the wheel is B, and the size of front bundle is  $B-A=4\sim 10\text{mm}$



When the front bundle of vehicle is not in this range, adjust the steering stem and the front bundle to  $4\sim 10\text{mm}$  then lock.

Note: When the size of front bundle of the vehicle is adjusted, drive the vehicle slowly and make sure that the handlebar can correctly restrict the driving direction of the vehicle.

#### Pressure of wheel


Use a gauge of tire pressure to check the air pressure. (The normal range of tire pressure is 4~6PSI)

Note: The check of tire pressure should be carried out under the condition which the tire is cooled. If the vehicle is driving in a state which the tire air pressure is not suitable, the operation and driving feel will be deteriorated, also will cause adverse effects such as eccentric wear of the tire.



Pattern of tire

Check the pattern of the tire. If the height is less than 3mm, please replace the new tire in time.



The inspection of rear wheel is the same as the front wheel.

### 3.6 Suspension system

Stop the vehicle in a horizontal position and press the vehicle several times according to position of the picture. If there is any shakes or abnormal noise, check the shock absorber for oil leakage, and whether the fastening parts are damaged or loose.



### 3.7 Gear shift & Fuel device

Change the gear position and check whether the gear shift is flexible and comfortable. If the gear shift is not comfortable, the angle of shift lever can be adjusted appropriately.



Gear  
shift

#### Fuel device

When checking the fuel system, the plastic parts need to be removed from the vehicle.

Check if the fuel pipe is aging or damaged. When the fuel pipe is aging or damaged, it should be replaced immediately. Check the vent pipe of fuel tank for cracks, bends, deformation, and replace it with new one if it is damaged.

### **3.8 Check of Throttle**

Check the normal flexible moving of throttle button. Press the throttle several times as the direction shown to check the flexible degree of the throttle. in normal circumstances, the throttle has no stuck phenomenon.



The throttle clearance is 3~5mm.

Adjustment the clearance when the throttle clearance is not within the specified range.




Remove the protective kit 1&2, turn the adjuster 3, and adjust the throttle to the normal flexible moving. Then adjust the rear tightening nut 4 and put on the protective kit 1&2.

If it does not reach the specified clearance or the operation is still not flexible after the adjustment, replace a new throttle line.

Adjustment of speed limit device (the model of EPA requires is unadjustable here)  
The speed limit device is used to limit the opening angle of the throttle, to realize the speed limitation of the vehicle.

Check the limit length of the speed limit thread, the thread length  $a = 25\text{mm}$ .

Adjustment method: loosen the lock nut and adjust with a screwdriver.



Note: For beginners, the speed limit device should be tightened. After the technology reaches a certain level, the speed limit device can be used to adjust the throttle opening angle. In addition, 25mm is the limit length of the speed limit thread. The EPA model must limit the adjust of throttle. After the factory adjusts it, the bolt is broken and changed to an unadjustable state.

### Option of front and rear shock absorbers

The front shock absorber is unadjustable.


The rear shock absorber of the vehicle is in five-speed adjustable state, and the factory defaults to the third gear position when it leaves the factory. It can be adjusted according to the needs of customers.

Adjustment method:

1. Adjust with a wrench of shock absorber ( shape of crescent )
2. As shown in the picture below, adjust to left to make the shock absorber softer, and to right to make the shock absorber harder.



adjustment wrench of shock absorber



Place for adjusting the soft and hard of shock absorber

## 4 Engine periphery

4.1 Maintenance

4.2 Fuel System

4.5 Disassembly and installation of engine

4.3 Intake system

4.4 Exhaust system

4.1 Maintenance

### Precautions

When repairing, please ensure that the vehicle is turned off and left for no less than 1 hour. Make sure the heating parts are cooled before the maintenance to avoid injury to the maintenance personnel.

- Be careful not to damage the frame, engine body, bolts, and cables during operation.
- When the engine is disassembled, the frame must be protected well with package.
- When the engine is removed, in order to protect the environment, using the corresponding container to fill with engine oil and fuel oil. When installing, the engine oil should be replenished as required.

• The following operations may not remove the engine from the vehicle:

- Oil pump
- Carburetor, air filter
- Cylinder head cover, starter motor, cylinder cover, cylinder body, camshaft
- Left-side cover, AC magneto
- Piston, piston ring, piston pin

• The following operations require the engine to be removed from the vehicle:

- crankshaft, box, main and auxiliary shaft

Tightening torque

See chapter1.5 Fastener tightening torque


## 4.2 Fuel System

### Note

Gasoline is very easy to catch fire, so fire and smoking are strictly prohibited in the workplace. Not only paying attention to the fire, but also high attention to electric sparks. In addition to the danger of explosion after the gasoline evaporates, so work should be carried out in a well ventilated area.

### Disassembly

Remove the plastic parts of the vehicle, loosen the oil pipe 1 at the oil switch, remove the bolt 2 in the oil switch , remove the oil switch, remove the mounting bolt of fuel tank , and then remove the fuel tank.



oil  
pipe1

oil switch  
bolt2



mounting  
bolt of fuel  
tank

## 4.3 Intake system

### Disassembly

Loosen the air filter clamp, loosen the exhaust pipe, and remove the air filter.



air filter clamp

#### Installation

In reverse order of disassembly. The oil pipe needs to be inserted into the joint head, and the clamp must be installed in the groove of the tube joint.

#### Installation

In the reverse order of disassembly. The exhaust pipe needs to be inserted into the joint head, and the clamp must be installed in the groove of the tube joint.

### 4.4 Exhaust system

#### Disassembly

Loosen the connection clamp of the muffler and exhaust pipe, remove the mounting bolt of muffler, and then remove the muffler.




clamp



Mounting bolt

## ZHE JIANG KAYO MOTOR CO., LTD

Remove the self-lock nut 3 which is connected to the exhaust pipe and the exhaust vent of the engine, and then remove the exhaust pipe.



### Installation

In the reverse order of disassembly, pay attention to check the seal 4 of the exhaust pipe and the graphite sleeve 5 which is installed in the muffler during the operation, and replace with the new ones when they are broken. If the self-lock nut is damaged, replace it with a new one immediately.

### 4.5 Disassembly and installation of engine

#### Disassembly

Note: The foot pedal must be removed first, then remove the engine from the frame.

1. Remove the side-cover 1 of engine first, then remove the chain.
2. Remove the ground wire, gear display wire, magneto motor wire, starter motor wire, exhaust pipe, high pressure cap, shift lever from the connection of engine.



starter motor wire


ground wire

magneto motor wire


gear display wire

exhaust pipe





3.Remove the bolt of upper power and then remove the lifting lug, bolt of rear power, bolt from bottom of the engine.



4.Remove the engine from the right side of the vehicle.

Installation

In reverse order of disassembly

## 5 Engine

### 5.1 Maintenance

Unit conversion table in this book

item	Unit conversion
pressure	1kgf/cm <sup>2</sup> =98.0665kPa    1kPa=1000Pa
	1mmHg=133.322Pa=0.133322kPa
torque	1 kgf·m=9.80665 N·m
volume	1mL=1cm <sup>3</sup> =1cc
	1L=1000cm <sup>3</sup>

torque

1kgf=9.80665N

### Warning

Please read the following explanation carefully, which emphasizes the specific meaning of the words “dangerous”, “warning” and “attention”, and pay special attention to the meaning of them when repair the engine.

Danger: Be wary of high risk

Warning: Be wary of middle risk

Note: Be wary of low risk

However, please note that the “Danger” and “Warning” which in this Service Manual are unlikely to cover all potential hazards during engine use and maintenance. Therefore, in addition to the relevant provisions of “Danger” and “Warning”, maintenance personnel must also have basic mechanical safety knowledge. If you are not sure of operating the entire maintenance process, please consult a more experienced senior technician.

#### General precautions

Warning: The correct maintenance process is very important for the safety of the maintenance personnel and the reliability and safety of the engine.

- When two or more people work together, they should pay attention to each other.
- When starting the engine indoors, make sure that the exhaust gas is discharged to the outside.
- when using poisonous or flammable materials in the work, must strictly follow the manufacturer's instructions and ensure that the workplace is well ventilated.
- Do not use gasoline as a cleaning liquid.
- To avoid burns, do not touch uncooled engine oil or exhaust system components
- If the systems of fuel oil, lubrication, and exhaust are repaired, they must be inspected for reticle and leakage.
- To protect the natural environment, do not dispose the unused parts.
- If you need to replace parts during maintenance, you must use genuine parts or recommended products provided by KAYO.


- Disassembled parts, which need to be reused, keep them in order, so that the assembly is not messy.
  - Ensure the use of special tools as specified in the service manual
  - Ensure that the components used in the assembly are clean, and the areas that require lubrication must be lubricated.
  - Use the specified lubricants, adhesives and sealants
- When tightening the bolts, screws, and nuts, first tighten the large size. Tightening from the inside to the outside according to the specified.
- Torque fastening
- Use a torque wrench to tighten the bolts according to the requirements, if there is grease and engine oil in the threads.

## 5.2 Introduce of fuel oil and engine oil

Fuel oil: use gasoline with 93#  
or above

Engine oil: SAE15W-40  
engine oil for 4-stroke  
motorcycle, quality grade is SG  
grade or above  
according to API classification, if  
there is no SAE15W-40 engine  
oil, according to the ambient  
temperature of the engine,  
Select the right oil as shown on  
the right.

**Warning: Engine oil must not be mixed  
with other brands of engine oil**



## 5.3 Engine running-in

The engine has many components for relative movement, such as pistons, piston rings, cylinder blocks, transmission gears, etc. Therefore, in the initial stage of using, it is necessary to carry out standard running-in. The running-in can make the moving parts adapt to each other and correct the working gap, which forms a good smooth friction surface that can withstand large loads, and the engine after

## ZHE JIANG KAYO MOTOR CO., LTD

---

making the running-in could have excellent performance and reliability.

The recommended running-in time is 20 hours and the specifications are as follows:

0 to 10 hours

Avoid continuous operation or continuously change the speed of the vehicle, or operate under a unfixed throttle position when the throttle state  $\geq 50\%$ ; after 1 hour of operation, let the engine cool for 5 to 10 minutes; avoid the sudden acceleration, the throttle change should be slowly.

10 to 20 hours

Avoid operation for longer periods when the throttle state is more than  $3/4$ , Do not use the full throttle state.

Code place of engine



Code place

Displacement indicator of engine



displacement  
indicator

## Maintain of engine


### Maintain

maintain times	Odometer reading			
	1000km	4000km	8000km	12000km
Fuel system	Clean	Clean	Clean	Clean
Oil filter	Clean	Clean	Clean	Clean
Control	Adjust	Adjust. clean	Adjust. clean	Adjust. clean
Carburetor	Clean	Clean	Clean	Clean
Air cleaner	Clean	Clean	Clean	Clean
Spark plug gap	Adjust	Adjust. clean	Adjust. clean	Adjust. clean
Valve clearance	Adjust	Adjust	Adjust	Adjust
Engine lubrication	Replace	Replace once per 2000km		
Filter media	Clean	Clean	Clean	Clean
Timing chain	Check	Adjust	Adjust	Adjust
Carburetor idle speed	Adjust	Adjust	Adjust	Adjust
Drive chain	Adjust and lubricate per 5000km			
Battery	Charge	Charge	Charge	Charge
Brake disc	Check	Adjust	Adjust	Replace
Brake system	Adjust	Adjust	Clean	Clean
Brake light switch	Adjust	Adjust	Adjust	Adjust
Illuminating system	Check	Check	Adjust	Adjust
Clutch	Adjust	Adjust	Adjust	Adjust
Shock absorber	Adjust	Adjust	Clean	Clean
Nuts/bolts	Tighten	Tighten	Tighten	Tighten
Front and rear wheel	Check	Check	Check	Replace
Turn handlebar bearing	Check	Adjust	Adjust	Replace

## 5.4 Maintenance of Engine Body

### 5.4.1 Disassemble, assemble and maintain cylinder head


Right view of the 125 engine is shown in the figure.




Left view of the 125 engine is shown in the figure




Remove the locknut of cylinder head from its holding place



Remove cylinder head. Check the state of paper pad. Replace if necessary.




Dismantle the fixing bolt of left cover.




Remove left cover and inspect the paper pad for damage. Replace if necessary.


Dismantle the fixing bolt of right cover.



Remove the right cover of cylinder head.  
Inspect the gasket for damage and replace if necessary.



Remove inlet/exhaust valve cap .Check the state of seal ring of valve cap and replace if worn or if reuse is questionable.



Remove the fixing bolt of timing driven sprocket.




fixing bolt

Remove the connecting bolt of cylinder head.




connecting bolt

Remove cylinder head assembly.



cylinder head

Remove timing driven sprocket. Inspect the timing driven sprocket for wear and damage. Replace if necessary.



timing driven sprocket

Check whether there is excessive carbon deposit in combustion chamber. Clean and replace if necessary.



combustion chamber

Remove the cylinder head. Pour gasoline into inlet/exhaust pipe to inspect the seal condition. Grind the valve and valve seat if there is gasoline leak into the combustion chamber.




oil seal


## ZHE JIANG KAYO MOTOR CO., LTD

---

Remove inlet/exhaust valve spring and check the state. Replace if necessary.



Inspect the oil seal of inlet/exhaust valve for damage. Replace if necessary.



Remove the spark plug to clean the carbon. Deposit and dust. Check the spark plug gap and set it to 0.6 to 0.7 if necessary.




For the troubleshooting of cylinder head ,please refer to the following table

Description	Damage Form	Problem	Cause	Correction
Cylinder head	Too much oil dirt or sand on the cooling fins.	Poor heat radiation of the fins on cylinder head.	The engine overheats.	Remove the oil dirt or sand
	Carbon deposit in the combustion chamber	Overheating head	The engine overheats	Remove the carbon deposit
	Failure of sparking plug threaded hole	Air leakage between the sparking plug and cylinder head	The engine starts hard or fails to start	Repair the threaded hole or replace the cylinder head
	Serious deformation	Air leakage between the cylinder head and cylinder	The engine starts hard or fails to start. Insufficient engine output ;Engine speed changes during idle run	Grind the cylinder head end surface or replace the cylinder head
	There are pits, ablation or pock marks, damages on the working surface of valve seat.	Air leakage between the valve and valve seat due to improper tightness	The engine starts hard or fails to start. Insufficient engine output; engine speed changes during idle run	Repair the valve seat
	The inner hole of valve guide is over worn	The fitting clearance between the valve and the valve is too large	Thick blue and white fume form the exhaust muffler pipe	Replace the valve guide
	The cylinder gasket is broken	Air leakage between the cylinder head and cylinder	The engine starts hard or fails to start. Insufficient engine output; Engine speed changes during idle run	Replace the cylinder head gasket


	The fixing nut is not properly tightened	Air leakage between the cylinder head and cylinder	The engine starts hard or fails to start. Insufficient engine output; Engine speed changes during idle run	Tighten the fixing nut
Spark plug	Improper clearance between electrodes	Weak or no sparking from the spark plug electrodes	Oil leakage between the cylinder and crankcase	Adjust electrode gap to 0.6~0.7mm
	The spark plug electrodes are jointed by carbon deposit	No sparking from the spark plug electrodes	The engine starts hard or fails to star	Remove the carbon deposit between the electrodes
	Excessive carbon deposit or oil dirt in the spark plug	Weak or no sparking from the spark plug electrodes	The engine starts hard or fails to start. Insufficient engine output; Engine speed changes during idle run	Remove the carbon deposit or oil dirt
	The spark plug insulator is damaged	Weak or no sparking from the spark plug electrodes	The engine starts hard or fails to start. Insufficient engine output; Engine speed changes during idle run	Replace with a new spark plug of the same type
	The spark plug is not properly tightened	Air leakage between the spark plug and cylinder head	The engine starts hard or fails to start. Engine speed changes during idle run	Tighten the spark plug

### 5.4.2 Disassemble, assemble and maintain cylinder block


Remove cylinder gasket and dowel pin to check for wear and damage. Replace if necessary.




Dismantle the fixing bolt of timing chain of guide wheel.




Remove the guide wheel of timing chain to inspect for wear and damage. Replace if necessary.




Dismantle connecting bolt of cylinder block.




Remove the cylinder block.



Remove the circlip of piston pin.



Remove the piston of piston pin to check whether it is damaged. Replace if necessary.



Inspect the paper pad for worn or damage .Replace if necessary.



Check whether there is residual gasket on cylinder. Clean with gasoline if necessary.



Check the state of cylinder inner wall .Replace if worn or if reuse is questionable.



inner cylinder wall

Check whether the internal diameter has exceed the limit value. Measure the diameter form upper, middle and lower position. The limit value is 50.05mm.Replace the cylinder block if it has beyond this value.



cylinder block

Troubleshooting of the cylinder body, please refer to the following table

Maintenance of Cylinder Body


Description	Damage form	Trouble	Cause	Correction
Cylinder body	Excessive oil dirt or sand on the radiating fins	Poor heat radiation of the fins on cylinder body	The engine overheats	Remove the oil dirt or sand
	Cylinder end surface badly distorted	Air leakage between the cylinder and cylinder head	The engine starts hard or fails to start .Insufficient engine output; poor idle speed and high fuel consumption	Grind the cylinder end surface or replace the cylinder body
	The cylinder is badly worn	The fitting clearance between the cylinder and position, position ring is too wide	The engine starts hard or fails to start .Insufficient engine output; Poor engine idle speed. Thick blue and white fume form the exhaust muffler pipe	Repair with boring machine or replace the cylinder body
	The cylinder		Oil leakage between the cylinder and crankcase	Replace the cylinder gasket

5.4.3 Disassemble, assemble and maintain crankcase


Remove the cover of right crankcase half.  
Check whether the oil seal of starting shaft  
and seal edge of gearshift lever are worn.  
Replace if necessary.




Check the state of right crankcase cover  
and replace if necessary.



Left view of right crankcase half is  
shown in fig and check whether  
bearing of main shaft and  
countershaft are worn. Replace if  
necessary.




Right view of right crankcase half is shown in fig and check the state of right crankcase half. Replace if necessary.



right crankcase half

Left view of left crankcase is shown below and check whether the oil seal of countershaft and oil seal edge of gearshift lever are worn .Replace if necessary.



gearshift lever oil seal

countershaft oil seal


Right view of right crankcase half is shown in fig and check whether bearing of main shaft and countershaft are worn. Replace if necessary.



countershaft bearing

main shaft bearing

Dismantle fixing bolt of left crankcase cover.




magneto stator

Remove the neutral indicator and check the state. Replace if necessary.




neutral indicator

Dismantle the fixing bolt of magneto stator and remove the stator.



magneto stator

Check the condition of left crankcase cover and replace if necessary.



left crankcase cover

**Troubleshooting of crankcase, please refer to the following table.**


Description	Problem	Trouble	Compucation	Correction
Crankcase	Crack in the crank case		Oil leakage from the crankcase	Repair or replace the crankcase
	Oil leakage from the joint of left and right crankcase		The crankcase gasket is worn out	Replace the gasket
	The threaded hole of oil drain plug screw is ineffective		Oil leakage from the threaded hole of plug screw	Repair of replace the crankcase
	The threaded holes of cylinder bolt are ineffective	Cylinder head retaining nut is impossible to screw up firmly, resulting in air leakage between the cylinder head and cylinder	The engine starts hard or fails to start. Insufficient engine output; Engine speed changes during idle run	Repair the threaded or replace the crankcase
	The bolt of the cylinder is broken	The same as front	The same as front	Replace the cylinder bolt

	The oil seal is damaged or the oil seal edge is damage/worn/aged	Oil leakage is ineffective	Oil leakage from the oil seal	Replace the oil seal
Right crankcase cover	The right crankcase cover is worn or cracked		Oil leakage form the case cover	Repair or replace the case cover
	The gasket of right crankcase is broken		Oil leakage between the case cover and the case	Replace the gasket
Left crankcase cover	The left crankcase cover is worn or cracked		Oil leakage form the case cover	Repair or replace the case cover
	The gasket of left crankcase is broken		Oil leakage between the case cover and the case	Replace the gasket


### 5.4.4 Maintenance of Crankshaft Connecting Rod

#### Disassemble, assemble and maintain crankshaft connecting rod


Remove the fixing bolt of crankcase from its holding place.



Remove left crankcase half. Take care not to forget the washer of mainshaft and countershaft when removing the left crankcase.




Remove the paper pad to inspect for wear and damage. Replace if necessary.



Remove the connecting rod assembly.



Inspect connecting rod bearing for wear and damage. Replace if necessary.




Check gap of big-end of connecting rod.  
Reset the gap if necessary.




bearing

Check diameter of piston pin using a micrometer. Replace the piston pin if the value is over the maintenance limit value.



piston pin

Check the axial and radial jumping of connecting rod bearing. Replace the conrod if the jumping is large.




Check the side gap between piston ring and piston groove using a feeler gauge. Replace the piston if the gap is too wide.




piston ring groove


Check whether there is excessive carbon deposit on piston top and groove. Remove if necessary.



Check the state of piston and replace if worn or if reuse is questionable. Measure diameter of piston skirt. Replace it if the value is beyond the maintenance limit value.



Assemble the piston ring according to the figure and check whether piston ring is damaged or the elasticity is weakened. Replace if necessary.



For the troubleshooting of crankshaft connecting rod mechanism, please refer to the following table.

Maintenance of Crankshaft Connecting Rod Mechanism

Description	Damage from	Trouble	Cause	Correction
Piston	Carbon deposit on piston		The engine over- heats	Remove the carbon deposit
	Carbon deposit in the ring groove	The piston ring is seized in ring groove	The engine starts hard or fails to start. Insufficient engine output;	
	Scuffing or scratches on the surface of piston skirt	Scuffing or scratches on the surface of piston skirt	Thick blue and white fume form the exhaust muffler pipe	
	The piston and ring groove are over worn	Excessive fitting clearance between the piston and the cylinder	The engine starts hard or fails to start. Insufficient engine output;	Replace the piston
	The piston pin hole is over worn	Excessive fitting clearance between the piston ring and the hole.	Striking sound of the piston pin and of the cylinder	
Crank pin	The crank pin is over worn	Radial and axes gap of the connecting rod big end is too large	Striking sound of the big-end bearing; Striking sound of the cylinder	Replace the crankshaft connecting rod
Bearing	The big-end needle bearing is over worn	Radial and axes gap of the connecting rod big end is too large	Striking sound of the big-end bearing; and of the cylinder	Replace the crankshaft connecting rod

## ZHE JIANG KAYO MOTOR CO., LTD

	The crankshaft bearing is over worn or damaged		Abnormal sound during the crankshaft bearing transmission	Replace the crankshaft bearing
Piston ring set	The piston ring is fractured	The piston ring is fractured	The engine starts hard or fails to start. Insufficient engine output; Thick blue and white fume form the exhaust muffler pipe	Replace the piston ring set
	The piston ring is over worn	The piston ring opening gap or the side gap is too wide		
	Insufficient elasticity of piston ring	It is impossible to tight the piston ring and the cylinder properly		
	Improper fixing	The piston ring gap is not staggered	Thick blue and white fume form the exhaust muffler pipe	Refixing the piston ring set
Piston pin	The piston pin is over worn	The fitting clearance between the piston pin and the hole is too wide	Striking sound of the piston pin and of the cylinder	Replace the piston pin
Connecting rod	The connecting rod small-end hole is over worn	The fitting clearance between the piston pin and the small-end is too wide	Striking sound of the piston and of the cylinder	Replace the connecting rod
	The connecting rod is crooked or twisted	The connecting rod is crooked or twisted	Striking sound of the cylinder	Replace the connecting rod
	The big-end hole is over worn	Radial and axes gap of the connecting rod big end is too large	Striking sound of the big-end bearing and of the cylinder	Replace the connecting rod


## ZHE JIANG KAYO MOTOR CO., LTD

Timing sprocket	The gear is over worn of damage		Abnormal sound during sprocket driving	Replace the timing sprocket
-----------------	---------------------------------	--	--	-----------------------------

### 5.5 Maintenance of Mechanism


#### 5.5.1 Disassemble, assemble and maintain valve mechanism

Remove rocker arm shaft



rocker arm shaft


Remove the rocker arm of inlet/exhaust valve and check the state




rocker arm

## ZHE JIANG KAYO MOTOR CO., LTD


Remove the timing cam, rocker arm ,  
rocker arm shaft to inspect for  
worn. Replace if necessary.




Remove the circlip of inlet and exhaust  
valve. Remove inlet valve stem and exhaust  
valve stem take care and don't miss the  
valve clip.



Measure length of valve spring to check  
whether the spring is damaged or worn.  
Replace if necessary.




Remove the spring of inlet and exhaust  
valve to inspect for wear and damage.  
Note: when assemble the valve spring ,  
make sure its dense end downward.



## ZHE JIANG KAYO MOTOR CO., LTD

Check the external diameter of valve stem using a vernier caliper. Replace the valve stem if the valve is beyond the maintenance limit valve.




valve stem

Measure the width of valve contact surface to check whether the contact surface is rough or abnormal. Replace the valve stem if the valve is large than 1.5mm.




valve contact surface

Check whether the valve stem is distorted. Replace if necessary.




valve stem


Inspect the timing camshaft bearing for wear and check the state of camshaft. Replace if necessary.




Check the gap of rocker arm shaft and rocker arm. Replace the rocker arm shaft and rocker arm if the gap is large.



Check the external diameter of rocker arm using a micrometer. Replace the rocker arm shaft if the valve is beyond the maintenance limit valve.




Remove the guide wheel of timing chain to inspect for wear and damage. Replace if necessary.



## ZHE JIANG KAYO MOTOR CO., LTD

Remove the fixing bolt of timing tensioner and check the state. Replace if worn or if reuse is questionable.



bolt

Remove the timing tensioner arm to inspect for wear and damage. Replace if necessary.




timing tensioner

Remove the oil tube and spring and check the state. Replace if necessary.




oil tube

Remove the small timing chain and check the state. Replace if necessary.



## ZHE JIANG KAYO MOTOR CO., LTD


Adjust valve clearance as follows; Remove the valve cap and check the condition.




Adjust valve clearance of front cylinder. Turn magnetic rotor counterclockwise to make piston locate at top dead center and make T mark aimed to the mark of left crankcase cover.



Check whether the O-mark on cam sprocket is aimed to the gap of cylinder head. Readjust if necessary.



Set the valve clearance of rear cylinder to 0.05mm~0.06mm.



## ZHE JIANG KAYO MOTOR CO., LTD

For the troubleshooting of engine distribution mechanism, please refer to the following table

### Maintenance of Distribution Mechanism

Descriptions	Damage form	Trouble	Cause	Correction
Valve oil seal	The edge of valve oil seal is worn, age or damage.		Thick blue and white fume form the exhaust muffler pipe	Replace the complete set of valve oil seal
Camshaft	The cam is cover worn		Insufficient engine output	Replace the camshaft
	The bearing of the camshaft is over worn or damaged	The axial or radial clearance of the bearing is too wide. Ineffective bearing swiveling or abnormal sound during	Abnormal sound heard during camshaft transmission.	Replace he camshaft
Rocker arm	The working surface is scratched or over worn		Valve striking sound	Replace the rocker arm
	The rocker arm shaft hole is over worn	Big gap between the rocker arm and rocker arm shaft	Valve striking sound	Replace the rocker arm
	The rocker arm shaft is over worn	Big gap between the rocker arm and rocker arm shaft	Valve striking sound	Replace the rocker arm shaft

## ZHE JIANG KAYO MOTOR CO., LTD


Valve	The valve clearance is too small	The valve is impossible to close completely	The engine starts hard or fails to start. Insufficient engine output; Engine speed changes during idle run	Readjust the valve clearance to 0.05~0.06mm
	The valve clearance is too big		Valve striking sound	Readjust the valve clearance to 0.05~0.06mm
	Carbon deposit on working surface	It is impossible to fit the valve and the valve seat tightly.	The engine starts hard or fails to start. Insufficient engine output; Engine speed changes during idle run	Remove the carbon deposit
	The working surface is over worn or has pits, pock marks, ablation or damage	It is impossible to fit the valve and the valve seat tightly.	The engine starts hard or fails to start. Insufficient engine output; Engine speed changes during idle run	Replace the valve
	The valve stem is over worn	The fitting clearance between the valve stem and the valve guide is too wide	Sound of valve leakage, Thick blue and white fume form the exhaust muffler pipe	Replace the valve

## ZHE JIANG KAYO MOTOR CO., LTD

	The valve stem is deformed	It is impossible to close the valve completely	The engine starts hard or fails to start	Replace the valve
Valve spring	The spring is ineffective or fractured	It is impossible to fit the valve and the valve seat tightly.	The engine starts hard or fails to start. Sound of the cylinder head	Replace the valve spring

5.6 Disassemble, assemble and maintain carburetor

Dismantle the fixing bolt of carburetor and circlip of air cleaner. Remove the carburetor. Remove and clean throttle cap



Clean the carburetor as follows:  
Remove the dirt and clean inner oil way. Dismantle the fixing bolt of float chamber cap.



fixing bolt

Remove the float chamber cap. Remove the water and debris in the cap if necessary. Check the state of seal ring and replace if it is aging



seal ring


Remove the float needle valve to inspect for wear and damage. Replace if necessary.




float needle valve

## ZHE JIANG KAYO MOTOR CO., LTD


Remove the throttle and oil needle and check the condition replace if necessary.



Check the state of float case and replace as necessary. Adjust the height of float case by moving the float up or down.



Take out the main jet to check whether the jet hole is clogged. Clean if necessary.



Remove the main nozzle to check whether small hole is clogged. Clean with compressed air if necessary.



Remove the idle jet and check for plugged.  
Clean the jet with compressed air if  
necessary




idle jet

Dismantle the mixture adjustment screw  
and inspect for worn. Replace if  
necessary. Adjust mixture screw of  
carburetor as the following. Standard:  
Tighten mixture screw, and turn it one  
and a half turns clockwise



mixture screw

Measure height of float case to check  
whether it is distorted or there is oil  
in the case. If height is incorrect  
which indicates carburetor leaks or the oil  
supply is insufficient.



Adjust the oil needle to the third tier. If the clip rises, concentration of mixture becomes  
dilute and if falls it becomes thick.

## **5.7 Maintenance of Intake/Exhaust System**

### 5.7.1 Disassemble, assemble and maintain intake system

Remove the air filter retaining ring

Remove the air filter




Remove the air filter to remove dust from the casing and remove the air filter to clean

For the troubleshooting of the air cleaner, please refer to the following table.

Description	Damage form	Trouble	Cause	Correction
Air filter	Too much dust on the filter core		The engine starts hard or fails to start. Insufficient engine output; poor performance of engine during idle run. Excessive fuel consumption. The exhaust muffler pipe	Clean the filter core
	The filter core is fractured or chapped.		Engine air suction noise is too loud	Replace the filter core

### 5.8 Disassemble, assemble and maintain exhaust system

Dismantle locknut of muffler



Dismantle suspension bolt of muffler to check whether the suspension support is damaged. Repair or or replace if necessary.



Remove the muffler to inspect for broken and damage. Replace or repair if necessary.



Remove the washer of muffler to inspect for damage. Replace if necessary.



## 5.9 Disassemble, assemble maintain the environmental protection

### Valve

Description	Damage form	Trouble	Cause	Correction
Exhaust pipe gasket	The gasket is broken	Exhaust pipe leakage	Engine exhaust noise is too loud.	Replace exhaust pipe gasket
Exhaust muffler	enclosure broken	The muffler enclosure is broken	Engine exhaust noise is too loud.	Replace exhaust muffler.

Inspect the locknut for tightness and tighten as necessary. Inspect the connecting circlip of air pump for tightness. Tighten if necessary.




Dismantle the fixing bolt of air pump and check the state of air pump.



Replace the air pump if it is worn or if reuse is questionable.



Remove the secondary inlet air cleaner and inspect for wear and damage. Clean and replace if necessary.



air cleaner

For the troubleshooting of environment protection valve, please refer to the following table.

Maintenance of environment protection valve

Parts	Damage form	Trouble	Cause	Correction
air pump	air pump broken or plugged	defective air pump	Emission fails to meet the standard	Replace
air cleaner	air cleaner damaged or plugged	defective air cleaner	Emission fails to meet the standard	Replace

## ZHE JIANG KAYO MOTOR CO., LTD

connecting hose	connecting hose get loose	noise is too big	Emission fails to meet the standard	Replace
Gasket	large noise from secondary inlet	air leaks form secondary inlet	Emission fails to meet the standard	Replace
muffler exhaust	too much carbon deposit on muffler exhaust	Poor combustion	Emission fails to meet the standard	Remove and clean

### 5.10 Disassembly, assembly, maintenance and management of electric starters

Remove the fixing bolts on the cover of left crankcase



bolt

Remove the fixing bolts of file display. Then remove the file display. And check for wear and damage. Replace them when necessary.



gear indicator

environment protection valve

Remove the cover of left crankcase



left crankcase cover


Remove the gasket and check the condition. If it is worn, please

replace it.

Remove the fixing bolt of magnetic stator and bolt of trigger.



gasket



stator

Check the status of stator with a multimeter. If it is worn, please replace with the new one.



stator

Disassemble the fixing nut of rotor



fixing nut

Remove the rotor with special tools



special tool

Remove the rotor and check if the rotor is demagnetized. Replace it when necessary.




rotor

Remove the fixing bolt of overrunning clutch



fixing bolt

Remove the clutch. Check for wear and damage to the clutch seats, rollers and springs. Replace it when necessary.




clutch holder

spring

roller

Check the wear and damage of the drive sprocket and drive gear. replace it when necessary.




driving gear

Disassemble the pressing plate of start sprocket




pressing plate

Remove the tension strip of the clutch and check its condition. If the tension strip is found to be worn or problems in use, replace it.




tension strip

Remove the circlip of the sprocket of starter.



sprocket circlip


Remove the drive sprocket and chains




driving sprocket

driving chain


Remove the fixing bolt of electric starter




Remove the electric starter



Check the electric starter for damage. Replace it when necessary.




Remove the disc of oil separation and check the condition. Replace it when necessary.




wear. Replace it when necessary.

Check the edges of the oil seal for



status of oil seal ring and replace it when necessary.

Remove the seal ring. Check the



For the troubleshooting of engine electric starter, please refer to the following table.

Maintenance of Electric Starter

Description	Damage form	Trouble	Cause	Correction
Starter motor	Carbon brush is over worn. The carbon brush spring is		Starter motor has insufficient rotation force or it is out of work.	Replace carbon brush
	fractured or has insufficient elastic force.		Starter motor has insufficient rotation force	Replace carbon brush spring
	Armature commutator surface is fouled.		Starter motor has insufficient rotation force	Clean the commutator surface With gasoline or alcohol

# ZHE JIANG KAYO MOTOR CO., LTD

<p>Armature commutator surface is spotted, burnt or damaged.</p>		<p>Starter motor has insufficient rotation force.</p>	<p>Polish the surface against the Commentator with fine abrasive Paper. Make the cut on the mica Plate between each commutator Piece with broken saw bit 0.5~0. 8mm deeper than the commutator surface. Remove the chip and Burr between each commutator.</p>
<p>Armature commutator surface is ablation or over worn.</p>		<p>Starter motor has insufficient rotation force or is out of work.</p>	<p>Replace starter motor</p>

